Smart Home Technology Seller / Buyer Handoff Information

August Factory Reset:
1. Tap the Menu button
2. Go to settings
3. Select your lock on the Settings page
4. Tap Factory Reset
5. Select Reset to confirm that you would like to proceed with the factory reset.

Nest Thermostat Reset:
1. Press the Ring to bring up the main menu
2. Turn to Settings and press the ring again to select
3. Turn the ring to Reset and press to select.
4. You can then restart the thermostat or choose which setting you'd like to reset.

Nest Protect Reset:
1. Press & hold the Button on Nest Protect. It will chime & glow blue.
2. Release the Button when Nest Protect starts speaking its version number. If you hold the button too long, the test will be cancelled.
3. Nest Protect will start a verbal countdown and tell you it's erasing all settings. You can cancel the reset by pressing the button again during the countdown.
4. After a few seconds your Nest Protect will restart.

Nest Cam Reset:
There is no need to reset the Nest Cam; if the WIFI is changed you will need to connect to the new wifi through the Nest app.

Lutron Caseta Smart Bridge Reset:
There is no need to reset the Lurton Caseta Smart Bridge; if the WIFI is changed you will need to connect to the new wifi.